

HOW TO FIT...

AUTO GATE LATCH



1.

Position catch on the gate post at the required height and mark fixing holes.



2.

Drill pilot holes and fix the catch with screws provided.



3.

Position the strike bar onto the gate at required height to engage into the latch and mark fixing holes.



4.

Drill pilot holes and fix with screws provided.



5.

Check gate / door opens and shuts without any catching.