

HOW TO FIT... CHAIN BOLT



1.

Position the bolt at the top of the leading edge of the door and mark fixing holes.



2.

Drill pilot holes and fix the bolt with screws provided.



3.

Drill pilot holes and fix the keep with screws provided. Once fixed, cut hole large enough to accept bolt shoot.



4.

Check gate / door opens and shuts without any catching.