



HOW TO FIT...

CABIN HOOK



1.

Position hook at desired level on door / gate or post and mark fixing holes.



2.

Drill pilot holes and fix with screws provided.



3.

Align staple with hook and mark fixing holes.



4.

Drill pilot holes and fix with screws provided.



5.

Check gate / door opens and shuts without any catching.



www.TIMco.co.uk / www.TIMco.ie



sales@TIMco.co.uk / sales@TIMco.ie

UK: + 44 (0)1829 261111

N.Ireland: +44 (0) 2890992305

Ireland: +353 (0) 4763538

TI-CH01-v1