



HOW TO FIT... **STRAP HINGES**



1.

Position hinge one strap onto the required position of the gate and mark the fixing holes.



2.

Drill pilot holes and fix the strap to the gate.



3.

Place the gate into the opening ensuring there is clearance from the bottom of the gate to the floor throughout the gate opening.



4.

Position the opposite strap of the hinge onto the adjacent gate / door. Mark fixing holes, drill and fix the hinge strap with screws provided.



5.

Check gate / door opens and shuts without any catching.



www.TIMco.co.uk / www.TIMco.ie



sales@TIMco.co.uk / sales@TIMco.ie

UK: + 44 (0)1829 261111

N.Ireland: +44 (0) 2890992305

Ireland: +353 (0) 4763538

TI-SH01-v1